


Main Rotor Blades

HM-V120D01-Z-01



Main Blades Holder

HM-V120D01-Z-02



Flybar Connector

HM-V120D01-Z-03



Swashplate

HM-V120D01-Z-04



Main Rotor Shaft

HM-V120D01-Z-05



Ball Linkage Set

HM-V120D01-Z-06



Servo Holder

HM-V120D01-Z-07



Stabilizer Set

HM-V120D01-Z-08



Tail Rotor Blades

HM-V120D01-Z-09



Canopy

HM-V120D01-Z-10




Screw Set

HM-V120D01-Z-11



Receiver (RX2433V)

HM-V120D01-Z-12



Main Shaft

HM-4#6(BE)-Z-08



Tail Shaft Set

HM-4G6-Z-12




Fixing Sleeve Set

HM-4G6-Z-13



Holder Frame

HM-4G6-Z-14



Main Frame

HM-4G6-Z-15




Skid Landing

HM-4G6-Z-16




Main Gear

HM-4G6-Z-18



Gear Set

HM-4G6-Z-19



Tail Driven Shaft

HM-4G6-Z-20



Tail Boom

HM-4G6-Z-21



Rudder Servo Rod

HM-4G6-Z-22



Tail Strut

HM-4G6-Z-23



Tail Gear Holder

HM-4G6-Z-25



Tail Blades Rocker

HM-4G6-Z-26



Tail Steering Set

HM-4G6-Z-27



Tail Blades Holder

HM-4G6-Z-28




Bearing Set

HM-4G6-Z-31




Tail Servo (WK-03-4)

HM-4G6-Z-34



Brushless Speed  
Controller (WK-WST-10A-L3)

HM-4G6-Z-36



Battery (3.7V 600mAh)

HM-4G6-Z-37



Servo (WK-02-1)

HM-4#6-Z-30



Brushless Main Motor  
(WK-WS-12-003)

HM-4#6-Z-32



Charger (4.2V 500mA)

HM-CB100-Z-21



2.4G Radio (WK-2403)

WK-2403